# POŁĄCZENIE SIECIOWE

## Pobierz aplikację Amica Smart

Pobierz aplikację Amica Smart w sklepie z aplikacjami (Google Play Store, Apple App Store), wyszukaj „Amica Smart” i znajdź aplikację. Pobierz ją i zainstaluj na swoim telefonie.
Możesz również pobrać aplikację, skanując poniższy kod QR.

## Zarejestruj się i zaloguj

Otwórz interfejs aplikacji → Kliknij „Spróbuj jako gość” → „Profil” (prawy dolny róg) → Ustawienia „⚙” (prawy górny róg) → Język → Wybierz swój język → Powrót do profilu → Kliknij domyślną nazwę użytkownika → Uzupełnij konto → Wprowadź adres e-mailowy → Uzyskaj kod weryfikacyjny → Wprowadź kod weryfikacyjny → Ustaw hasło → Dodaj urządzenie.

## Połącz urządzenie z Amica Smart

1. Po włączeniu zasilania ikona Wi-Fi zacznie migać. W tym momencie nacisnąć i przytrzymać przez ponad 3 sekundy przycisk temperatury (Temp.), aby wejść w tryb sieciowy.
2. Po wejściu w tryb sieciowy otworzyć aplikację; pojawi się odpowiedni interfejs. Kliknąć na urządzenie, aby nawiązać połączenie postępując zgodnie z instrukcjami.
3. Aby sterować urządzeniem za pomocą aplikacji, po pomyślnym połączeniu, należy najpierw ustawić pokrętło na program wirowania (Wirowanie), a następnie krótko nacisnąć przycisk temperatury (Temp.). Oba warunki muszą zostać spełnione jednocześnie, aby sterowanie było aktywne. Gdy pokrętło ustawione jest na inny program lub gdy znajduje się na programie wirowania (Wirowanie), ale przycisk temperatury (Temp.) nie został krótko naciśnięty, aplikacja może jedynie wyświetlać status urządzenia, a sterowanie nie będzie możliwe.
4. W każdym przypadku, jeśli drzwi urządzenia zostały otwarte – również po zakończeniu prania i wyłączeniu urządzenia – aby ponownie umożliwić sterowanie z aplikacji, należy zamknąć drzwi, upewnić się, że pokrętło jest ustawione na program wirowania (Wirowanie), krótko nacisnąć przycisk temperatury (Temp.). Dopiero wtedy sterowanie z aplikacji zostanie przywrócone.

Jeśli funkcja Wi-Fi nie jest potrzebna, aby włączyć lub wyłączyć moduł Wi-Fi, nacisnąć i przytrzymać przez ponad 3 sekundy jednocześnie przycisk opóźnienia zakończenia (Gotowe za) i przycisk temperatury (Temp.). Po wyłączeniu ikona Wi-Fi zgaśnie, a funkcja zostanie wyłączona.

Amica S.A. niniejszym oświadcza, że typ urządzenia radiowego: pralka, model: EWA8C814ADiSJ_CX, GWA8C914ADiSH_CX, EWA8C1014ADiSJ_CX, pralko-suszarka, model: AWD8C10A/DDiSJ_CX
jest zgodny z dyrektywą **2014/53/EU**.
Pełny tekst deklaracji zgodności UE jest dostępny pod następującym adresem internetowym: **www.amica.pl**

## Częstotliwość pracy produktu

| RF | Częstotliwość nadawania | Maksymalna moc nadawania |
|---|---|---|
| 2.4G WiFi | 2400-2483.5MHz | <19.5dBm |

**Uwaga:** Produkt nadaje się do pracy w temperaturze 4~40°C.

# NETWORK CONNECTION

## Download the Amica Smart app

Download the Amica Smart app on an app market (Google Play Store, Apple App Store), search for Amica Smart and find the app. Download and install it a your phone. You can also download the app by scanning the QR below.

## Register and log in

Open the app interface → Click "try as a guest" → "Profile" (lower right corner) → Setting "⚙" ( upper right corner) → Language → Select your language → Back to profile → Click its default name → Fill in the details → Enter your email address → Get a verification code → Enter the verification code → Set a password → Add a device.

## Connect your washing machine/ washer- dryer to Amica Smart

1. After turning on the power, the WIFI icon flashes. At this time, press the Temp key for more than 3 seconds to enter the network mode.
2. After entering the network mode, open the app and the following interface will appear. Click the device to connect according to the operation instructions.
3. After successful connection, to operate the machine through the APP, you must first select the Spin mode on the knob and then briefly press the Temp button. Both conditions must be met simultaneously to enable effective control of the machine. When the knob is in other modes or when the knob is in Spin mode without pressing the Temp button, the APP can only display the machine's status and cannot perform any controls.
4. In any case, if the door of the machine has been opened, including opening the door after the washing is finished and the machine is turned off, to restore the control of the APP, you need to close the door first, ensure that the pointer of the knob points to Spin, and then short press the Temp key to control again.

If you do not need to use the WIFI function, long press the Delay and Temp keys for more than 3 seconds to enable or disable the WIFI function of the machine. After disabling, the WIFI icon will be turned off and the WIFI function will be disabled

Amica S.A. hereby declares that the radio equipment type: washing machine, model: EWA8C814ADiSJ_CX, GWA8C914ADiSH_CX, EWA8C1014ADiSJ_CX, washer-dryer, model: AWD8C10A/DDiSJ_CX complies with Directive **2014/53/EU**.
The full text of the EU declaration of conformity is available at the following internet address:

**www.amica.pl**

## Operating Frequency of Product

| RF | Transmit frequency | Maximum transmit power |
|---|---|---|
| 2.4G WiFi | 2400-2483.5MHz | <19.5dBm |

**Note:** The product is suitable to operating in the environment of 4~40°C.