	TABLE OF CONTENT	WATCH OVERVIEW	PACKAGE CONTAINS	CHARG
	What's in the Box 01 Watch Overview Charge the Watch 02 Turn the Watch on and off 03 Watch Navigation 04 Button Home Screen Navigation	 Noise Health Noise Buzz Clock Rapid Health Workouts Sports Record Reminders 		Before u to its ful On a sin Note: Th usage an CHARG • Plug th socket.
NoiseFit Endeavour	 Setup & Pair the Watch BT Call Connectivity & Removal Watch Features General Device Information and Tips Safety& Handling instructions 16-17 Medical Devide Interference Disposal Information Customer Support 19 	• Music • Weather • Watch Faces • Flashlight • Calculator • Settings	NoiseFit Endeavour Smartwatch x 1	Place t While y Once t
before using the product	User Manual for NoiseFit Endeavour	User Manual for NoiseFit Endeavour	01	I I User Ma



Alarm

You can set alarms in the NoiseFit app and they will sync with the watch. You can add, delete, and enable/ disable alarms. You can also label alarms to identify them.

Timer

You can set a timer with a pre-set duration on the watch and the timer will remind you when the time

Stopwatch

A stopwatch can be set on the watch. You can also set lap times on the stopwatch.

World clock

You can use this feature to see the time of 5 cities on your watch. Go to the NoiseFit app, add cities of which you want to see the time of.

Pomodoro

Utilise the 'Pomodoro Technique' to enhance your productivity. Set your desired 'Focus Time' and start focusing. Press on II button to pause. > button to play and × button to stop Note: Your watch will go on DND mode while using this feature.

User Manual for NoiseFit Endeavour



RAPID HEALTH

Use this feature to measure a wide range of healthy indicators with just one touch.

WORKOUTS

You can choose from 100 workout modes. You can take your pick and ad more workouts from the app. This feature also lets you control music wh working out. You can also view the exercise records in the app.

SPORT RECORD

You can check the progress report of your workouts in this feature.

REMINDERS

You can add or edit reminders on the app.

MUSIC

You can control your favourite songs and podcasts that play from your phone, right on your wrist as long as the watch is connected to the loiseFit app on your phone. You can play/pause music, go to the next/previous track and increase/decrease the volume.

WEATHER

NoiseFit Endeavour supports 5-day weather viewing in a location of you as long as it is synced with the NoiseFit app. You can view to current weather and for the next 4 days as well. Open the Weather app your watch and change the location to see the weather of your current location

09 User Manual for NoiseFit Endeavour



WATCH FACES

You can switch between different watch faces in the watch hoose and download cloud based watch faces. You can also create your own watch faces in the NoiseFit app.

Changing the watch face

Give your screen a personalised style by changing or customising he watch face from the NoiseFit app or the watch.

On the watch

Touch and hold the home screen. Swipe and choose from the watch faces.

In the app

Go to watch faces, select the watch face of your choice and tap 'save' to change the watch face.

You can use this feature to turn on the screen ightness and see your surroundings better.

CALCULATOR

You can use this feature to do basic calculations through your smartwatch.

10 User Manual for NoiseFit Endeavour



Ringtone Vibration

Wrist Awake



DND

end time and set.

Menu View



So to the Flashlight. Tap to turn on.







ARGING NOISEFIT ENDEAVOUR SMARTWATCH

e using your NoiseFit Endeayour for the first time, charge the battery s full capacity. Use the charging cable provided with the watch to charge. a single charge, NoiseFit Endeavour can last up to 7 days. : The battery life and time to fully charge your device may vary as per and other factors.

ARGE NOISEFIT ENDEAVOUR

- g the USB cable into a power adaptor and the adaptor into an electrical ket. (Power adaptor not included).
- ce the magnetic charger on the magnetic charging points of the watch.
- hile your watch is charging, the screen will show its progress.
- ce the battery is fully charged, remove the charger.



Manual for NoiseFit Endeavour

02 User Manual for NoiseFit Endeavour

POWER ON

POWER OFF

• Press and hold the upper side button for a few seconds to turn on the watch.

+ Press and hold the upper side button for a few seconds.

To preserve battery, the watch screen turns off when not in use.

Select 'Power Off' and confirm to power off.

WAKING UP THE WATCH

Turn the screen back on by:

• Turning on the wrist sense.

Pressing side buttons.



The NoiseFit Endeavour smartwatch has an AMOLED touch screen. Navigate the watch by tapping on the screen, swiping side to side, up and down and pressing the side button.

BUTTON NAVIGATION

03 User Manual for NoiseFit Endeavour

• Press the upper side button to turn on the display and to go to the main menu.

- Turn the upper side button to change watch faces. • Press the upper side button 5 times to activate SOS.
- Press the upper side button to turn on the display.

Press the lower side button to access sports modes shortcut.

HOME SCREEN NAVIGATION





APP SET-UP

- Before pairing, make sure that your smartphone and smartwatch are payt to each other. The app will ask for personal information such as height, weight and sex to calculate your stride length, distance covered and calorie burn rate.
- Turn on BT and the location on your mobile device.
- On your smartphone, download the NoiseFit app from the Play store or the App store and install it.
- Create an account or log in using an existing account.

Note: Ensure that your smartphone is running on Android 9.0 & + or iOS 11.0 + and is connected to mobile data or a Wi-Fi network.

PAIRING THE WATCH

- Open the NoiseFit app and allow the BT and GPS positioning to be turned on.
- Feed in your personal information and health goals in the app.
- Go to the 'Device' page in the app, Tap on 'select device' Select the watch name and MAC address to link the watch.
- Or you can follow the steps below:
- Turn on the watch.
- Scan the QR code on your watch using the NoiseFit app on your phone.
- Select 'Pair with device' and wait for it to pair.
- Select 'Add Device'. Choose your device from the range of devices. On iOS: Choose BT pairing when you receive a pairing prompt.

On Android: Connect it directly. 04 User Manual for NoiseFit Endeavour



BT CALL CONNECTIVITY

To establish BT calling connectivity, follow these steps.

For automatic connection

After pairing the watch with the NoiseFit app, the watch's calling BT would be activated. Now connect it with your phone's BT to use the calling feature conveniently.

Manual connection

In case the BT calling connectivity has not been established earlier, you'll have to do the steps manually. Go to Settings. Search for device and pair your smartphone to attend call from the watch.

BT CALL CONNECTIVITY REMOVAL

In Android devices, to remove the BT connection, you can unpair the watch from the phone's BT settings. Go to the phone's BT settings and disconnect Endeavour calling • xxxx (xxxx last 4 digits of watch's mac address).

In iOS devices, to remove the BT connection, you can unpair the watch from the phone's BT settings. Go to the phone's BT settings and disconnect NoiseFit Endeavour and Endeavour calling • xxxx (xxxx last 4 digits of watch's mac address).

05 User Manual for NoiseFit Endeavour

NOISE HEALTH

Noise Health Suite has a collection of wellness features that take a holistic route.

Activity

You can check your daily activity progress in terms of the calories burned, distance covered, active time and stens taken

NoiseFit Endeavour supports 24/7 heart rate tracking.

You can select the measurement frequency in the app

can view the all-day data on the watch and app.

is no space between your watch and the wrist.

settings. To measure your heart rate in real-time, go to

the 'Heart Rate' monitor and tap on 'Tap to Measure.' You

Note: Make sure your arms and wrists are still and there

NoiseFit Endeavour supports the viewing of the highest

and lowest Blood Oxygen levels of the day. To measure

your blood Oxygen level in real-time, go to the 'SpO2'

Note: Make sure your arms and wrists are still, and there

Heart Rate

Blood Oxygen

06 User Manual for NoiseFit Endeavour

16 User Manual for NoiseFit Endeavour

monitor and let it measure.







is no space between your watch and the wrist.

You can view your most recent sleep record and sleep quality in various sleep stages, in the NoiseFit app. The feature will measure the device records of the user's slee cycle, sleep states (light and deep sleep), wake time

Breathe

This feature helps you adjust your breathing rhythm as per your convenience. You can choose from 3 speeds (fa slow) to adjust your breathing duration. Go to the 'Breathing duration in the 'Breathing duratin the ' choose the time duration and speed and tap on start to ent cycles of breathing and inhalation.

Stress

NoiseFit Endeavour supports 24-hour stress level measurement and viewing of all-day measurement data. To measure the stress evel in real-time, go to the 'Stress' feature and wait for it to

Note: Make sure your arms and wrists are still and ther between your watch and the wrist.

NOISE BUZZ

You can use this feature to manage calls from the watch. Make sure your watch is connected to your smartphone via BT. Go to Noise uzz to access recent logs, make calls using the dial pad and access contacts

Note: If the watch is connected to your smartphone via BT, all call will be directed to the watch. During a call, tap the switch i your watch to switch to your phone and take the call there.

07 User Manual for NoiseFit Endeavour



() ∩oise

How does the watch estimate how many calories have been burned?

NoiseFit Endeavour estimates how many calories you've burned based on the physical data you entered when you set up your account.

How do I change my activity goals?

You can do it through the NoiseFit app. Click on your image on the left top corner of the home page, select 'My goals' and Click on 'Edit', Change your goals and confirm.

How do I log my weight?

You can log in your weight the first time you set up your NoiseFit app. However, you can update the weight later via the NoiseFit app.Click on your image on the left top corner of the home page, go to 'My Profile', click on edit to change o update your weight. You can update your birthday, height, gender, interests and email ID as well.

SAFETY AND HANDLING INSTRUCTIONS:

• The device includes an in-built rechargeable battery. The battery life may degrade near the end-of-life of the battery. Do not attempt to change the battery yourself in any event as you may end up damaging the device and/or the batteries posing a safety hazard on subsequent usage.

· Please do not tamper with the battery terminals as it may result in battery leakage, overheating, explosion or a fire hazard.

 Please do not pierce or disassemble the device as it may damage the battery causing the battery liquid to leak causing irritation to your skin if exposed to the liquid.

Damaged battery may also be prone to overheating or causing a fire hazard.

• Do not place the device near fire or expose it to excessive heating as it may cause the battery to explode posing a safety hazard.

15 User Manual for NoiseFit Endeavour

• Only use Noise approved chargers and cables that are specifically designed for use with the device. Unapproved charges and cables may damage the device and also pose a safety hazard for the user.

• If the device emits a foul smell or burning odour, please stop using the device immediately and contact the Noise approved service centres.

• The device can be used in ambient temperature ranges of -20°C to 55°C. Using the device outside of the prescribed temperature range may damage the device. Do not use the device in a sauna or steam room.

• Do not use household cleaners to clean the device. Use soap-free cleaners instead. The device is dust and water resistant (rated at IP68). Following tips are to be

ollowed for a safe upkeep of the device:

-Please make sure that the device is not exposed to sea water or used in deep waters. -Do not expose the device to high pressure water flow. -Wipe the device clean of water with soft and clean cloth if exposed to water.

-Leave the device to dry up naturally.

Do not open the device if it stops functioning upon exposure to water and despite following the above steps. Visit an authorized service centre for getting the device checked.

MEDICAL DEVICE INTERFERENCE:

The device includes components that may cause interference when worn with medical devices like pacemakers, and other magnet-sensitive devices. In case you intend to use a medical device, please consult your physician before using the device. Also, in case the device is allowed to be worn with the medical devices by your physician, ensure sufficientseparation between the device and the medical device during all times

MEDICAL USE ADVISORY:

Unless otherwise specified, the device and any associated app-based or Noise provided services are not suitable to be used as medical devices. In particular, the device and associated app-based or Noise provided services are not intended to diagnose, treat, cure o prevent any disease/health condition. We develop products and services to track daily activ and wellness information as accurately as possible. The accuracy of devices is not intended to be equivalent to medical devices or scientific measurement devices. HEARING LOSS:

Prolonged exposure to high volumes may result in permanent damage to hearing capabilit While using the device, ensure that the sound levels are maintained at optimum level.

CHOKING HAZARD:

The device is not a toy and it contains small components that could cause a choking hazard.Accordingly, the device is not intended for use by or left unattended around small children or pets.

SKIN IRRITATION HAZARD:

In some cases, prolonged use of or exposure to the device may cause skin irritation or allergies in some users. To reduce the possibility of irritation, keep the device clean and dry. If you feel soreness, tingling, numbness, burning or stiffness on any part of your skin while or after using the watch, please immediately discontinue use.

17 User Manual for NoiseFit Endeavour

18 User Manual for NoiseFit Endeavour

indicative that the device and/or any of the associated accessories (like USB cable, chargerand the like) thereof should not be disposed with household/domestic waste. In accordance with the regulation of the Ministry of Environment, Forest and Climate Change, Noise has been granted Extended Producer Responsibility Authorisation (EPR Authorisat number: B-29016 (1910)/(EPR)/20/WM-III Division dated 04.03.2021) by the Central Pollution control Board. Accordingly, Noise is committed to contribute its bit wards protecting the environment by providing customers with the option of depositing their Noise devices, which have reached their end-of-life, at authorised e-waste collection entres. The details of our e-waste collection centres and our e-waste policy is available at the link: https://www.gonoise.com/pages/e-waster-management. By recycling, reusing materialsor other forms of utilising old devices, you are making an important contribution toprotecting our environment. Together we could make a difference!

CUSTOMER SUPPORT

DISPOSAL INFORMATION:

If you experience any problem with the watch, it may be fixed by restarting your watch. For any assistance, please reach out to us at link support.gonoise.com

At Noise, we are committed towards protecting the environment and prevent any damage to

the same by way of irresponsible disposal of e-waste generated from electronic devices. In

our endeavour to collaboratively protect the environment, we urge our customers to help

Noise to reduce the impact of e-waste on the environment. The following symbol is

19