NoiseFit Halo Plus UM - 84 x 84 mm

	TABLE OF CONTENT		WATCH OVERVIEW		WHAT'S IN THE BOX	USING THE NOISEFIT HALO PLUS SMARTWATCH
	 • What's in the box	01	Activity	• Flashlight		Before using your NoiseFit Halo Plus for the first time, ch
	 Watch overview	01	Workouts	Settings		capacity. Use the charging cable provided with the wate charge, NoiseFit Halo Plus can last up to 7 days.
	 Charge the watch	02	• SpO2	• Cycle Tracker		
	 • Turn the watch On and Off	03	Heart Rate	*		Note: The battery life and time to fully charge your device usage and other factors.
	 Watch navigation	04	• Sleep			
	 -Side button navigation	04	Breathe			CHARGING THE NOISEFIT HALO PLUS SMARTWATCH
	 -Home screen navigation		Contacts			 Plug the USB cable into a power adaptor.
NaisaEit	 • Set-up	05	Call History			 Plug the power adaptor into an electrical socket. (Power
NoiseFit	 -App set-up	00	• Dial Pad		NoiseFit Halo Plus Smartwatch x 1	
Lists Dive	 -Pair the watch		• Weather			Place the magnetic charger on the magnetic charging
Halo Plus	 • Watch features	06-11	• Music			• Once the battery is fully charged, remove the charger.
		12-13			<u> </u>	1
ELITE EDITION	 General device information and tips	12-13	Reminders			
	 Regulatory information	14	 Stopwatch 			
	 Disposal and recycling information 	14	• Alarm			
	 Maintenance instructions 	16	• Timer		T	
	 Safety instructions	17	 Watch Faces 			
	 Customer support	17	 Stress 			
					Charging Cable x 1 User Manual x 1	
					User Manual x 1 Warranty Card x 1	
Please refer to this manual before						
using the product	User Manual for NoiseFit Halo Plus		User Manual for NoiseFit	it Halo Plus	01	User Manual for NoiseFit Halo Plus



You can set a countdown with a pre-set duration on the watch or set your own timer. The watch will remind you when the time is up. Go to 'Clock', select 'Timer' and se it as per your requirement.

ALARM CLOCK

You can set alarms from the NoiseFit app and it will sync with the watch.

WATCH FACE

You can switch between different watch faces in the watch. Choose and download cloud-based watch faces of create tour own watch face sin the NoiseFit app.

Changing the Watch Face

Give your screen a personalised style by changing or cutomising the watch face from the NoiseFit app or the watch.

On the Watch

Touch and hold the home screen. Swipe and choose from watch faces.

In the App

Go to 'Watch faces', select the watch face of your choice and tap save to change the watch face.

User Manual for NoiseFit Halo Plus

ALWAYS ON DISPLAY

You can turn on the 'Always on Display' feature and choos watch display between pointer and digital.

SETTINGS

- Brightness Set the brightness level as per your preference.
- Set the vibration level as per your preference.
- Wrist awake Turn on wrist awake and set the auto screen off as per your preference.

• DND You can choose to turn on the DND.

 Menu View You can choose the way you want to see the watch features as per your preference

• QR Code Scan the QR code to connect to the app.

 Device Info You will find all the information related to the device here, including device name and Bluetooth name and version.

09 User Manual for NoiseFit Halo Plus

• Rehoot Power off















Go to 'Power off' to turn your smartwatch off.

You can choose to reset your smartwatch. If you



DEVICE INFORMATION AND TIPS

DEVICE INFORMATION

The NoiseFit Halo Plus smartwatch contains the following: • 1.46" AMOLED touch screen Blood oxygen monitor Stress monitor IP68 Waterproof 100 Sports modes

22mm Quick change pins

The NoiseFit Halo Plus smartwatch stores your activity of between the time you sync your watch to the NoiseFit includes your steps, distance, calories, active minutes, h and workout data. We recommend syncing the watch to

TIPS

How do I update my NoiseFit Halo Plus?

You can update your NoiseFit Halo Plus via the NoiseFit a 'Me', go to 'Settings' & check for version updates.



1		I set the set of the s			the second se
ity data for up to 7 days in Fit app. Activity data tes, heart rate, sleep duration ch to the app daily. eFit app. In the app, select	 How do I find my watch's current firmware version? You can find the watch's current firmware on the watch. Go to 'Settings', tap on 'System' then 'System info' to view the current firmware version. On the NoiseFit app, tap on 'Device' and choose 'Device Version' to know your current firmware version. How does the watch estimate how many calories have been burned? NoiseFit Halo Plus estimates how many calories you've burned based on the physical activity data and your heart rate. How do I change my activity goals? You can do it through the NoiseFit app. In the app, select 'Me' and go to 'Exercise Goals' to change your goals. How do I log my weight? You can log in your weight the first time you set up your NoiseFit app. However, you can update the weight later via the NoiseFit app. Go to 'Me', and tap on the section with your name on it to update your weight. You can update your nickname, birthday, sex and height as well. 	DSPOSAL AND RECYCLING INFORMATION Electrical and electronic devices may not be disposed off with domestic waste. Consumers are obliged by law to return the electrical and electronic devices at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. By recycling, reusing the materials or other forms of utilising old devices, you are making an important contribution to protecting our environment. SECONDECTION CONDECTION DSA: Federal Communications Commission (FCC) Statement This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: This device may cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation. Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against muful interference in acidential installation. This equipment penerates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to readio communications. However, there is no guarantee that interference will not occur in a particular installation.		If this 76 equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Consect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. The NoiseFit Halo Plus Watch is not a toy. The watch contains small children or pets. Unless otherwise specified, devices and services are not a medical device and are not intended for use by small children or pets. Unless otherwise specified, devices and services are not an medical device and are not intended to diagnose, treat, cure or prevent any disease. We develop products and services to track daily activity and wellness information as accurately as possible. The accuracy of devices is not intended to be equivalent to medal devices or scientific measurement devices. Prolonged contact may contribute to skin irritation or allergies in some users. To reduce the possibility of irritation, keep the watch and watch band clean and dry. Don't wear it too tight and give your wrist a rest by removing the watch, please immediately discontinue use.	 MAINTENANCE INSTRUCTION: Keep the device dry and clean as moisture and dirt can build up irritation. Do not wear the device too tigf lightly in contact with your skin a between the wrist strap and you Do not use household cleaners instead. For stains that are difficult to re alcohol. The device is not suitable for d suitable for swimming pool, sho Keep it away direct sunlight, hi may damage the band over time SAFETY INSTRUCTIONS Do not cleaseswhe temperature durin deformation of the battery or ev Charge the battery in a cool, ve Do not open, crush, bend, defo batteries. In the event of a batter contact with skin or eyes. If this water (DO NOT RUB THE EYE) or
12	User Manual for NoiseFit Halo Plus 13	User Manual for NoiseFit Halo Plus	14	User Manual for NoiseFit Halo Plus	15 User Manual for NoiseFit Halo Plus





A stopwatch can be set on the smartwatch. You can also setlap times in the stopwatch.

STRESS

NoiseFit Halo Plus supports 24-hour stress level measurement and viewing of all-day measurement data. To measure stress levels in real tim, go the 'Stresslevel' featureand wait for it to measure. Make sure your arms and wrists are still and there is no space between your watch and the wrist.

BREATHE

he breathe feature helps you adjust your breathing rhythm as per your convenience. You can choose from 3 speeds (fast, moderate and slow) to adjust your breathing duration. After the session, you can also see the change in beats per minute. Go to the 'Breathe' feature choose the time duration and speed. Tap on 'start' to enter the cycles of breathing and inhalation. During this period, if you swipe right or press a button, breathing is interrupted. You can choose to practice again or complete the cycle.

• Do not short-circuit. Short-circuiting may damage the battery. Short-circuiting

• Keep the batteries out of children's reach and in a safe place to prevent danger.

• Do not dispose off batteries in the fire as that may cause an explosion. Dispose

off used batteries in accordance with your local regulations. Do not dispose it as

• Use only the charging cable supplied to charge the battery. Do not charge for

maintenance should be performed by authorised technicians only. Any device

• To prevent device damage, accessory damage and device failure, always protect

If you experience any problem with the watch, it may be fixed by restarting your

watch. For any assistance, please reach out to us at support.gonoise.in

• Do not attempt to repair or maintain the watch yourself, service and

failure should be referred to our after-sales service personnel.

positive and negative terminals of the battery.

• Do not use your product in a sauna or steam room.

• Do not place the batteries in the water.

the device against strong impact or shock.

can occur when a metallic object, such as a coin, causes the direct connection of





07

NOISE BUZZ

NoiseFit Halo Plus supports Bluetooth Calls. You can dial, answer, silence and reject calls from the smartwatc as long as the watch's Bluetooth is connected with the smartphone and is within Bluetooth range.

CONTACTS

You can choose to sync 10 conacts from your phone into thr NoiseFit App which will be reflected on your watch. Choose from the list of saved contacts in your smartwatch and call.

CALL HISTORY

Choose from the call logs to call any of the previously contacted numbers.

FLASHLIGHT

You can use this feature to turn on the screen brightness and see your surroundings better. Go to Flashlight. Tap to turn on.

06 User Manual for NoiseFit Halo Plus

household waste.

more than 24 hours.

CUSTOMER SUPPORT

User Manual for NoiseFit Halo Plus



08

IONS

lean regularly and especially after prolonged use ild up underneath the band and can cause skin

o tight but make sure that the bottom sensor is skin and there is a gap of about one finger's width l your wrist.

ners to clean the device. Use soap-free cleaners

to remove, it is recommended to scrub with

for diving, swimming in the sea or sauna; it is shower (cold water) and swimming in shallows.

nt, high temperatures or humid conditions as it time.

attery on your own.

lo Plus to extremely high or low temperatures. during charging could cause heat, smoke, fire or or even explosion.

ol, ventilated room.

deform, puncture or shred secondary cells or battery break or leak, prevent battery liquid f this happens, immediately flush the areas with E) or seek medical help.

∩0ISE