Warranty and Safety Guide

Safety Instructions

Read all information before using the device to ensure safe and proper use.
- This smart watch is suitable for working in an environment of 0°C to 40°C. Temperature for storage should be between 0°C and 35°C. Excessively high or low temperatures may damage the smart watch or reduce the battery's lifespan.
- When charging, please keep the device in a well-ventilated area. Please charge this smart watch in an environment between 0°C and 35°C. Charging outside this temperature range may cause battery leakage, other accessories to present potential electric shock, fire, explosion or other hazards.
- Rack over can't be removed.
- Do not allow the device or battery directly in sunlight, near/inside sources of heat or on a flammable surface to prevent fire. Failure to do so may result in damage to your device.
- Do not attempt to open your device's parts or internal circuits, do not use it in dusty, smoky, damp or dirty environments or near magnetic fields.
- Power off your device in any area with a potentially explosive atmosphere, in blasting areas, near blasting caps and comply with all signs and instructions.
- If any part of the product is cracked or damaged, discontinue use immediately and contact the realme Service Center.
- The battery can be charged and discharged hundreds of times at least, but it will eventually wear out.
- Do not charge the battery over 12 hours.
- Use the battery only for its intended purpose. Improperly stuck or cut the battery, as it may cause battery leakage, overheating, explosion or fire.
- **Precautions for using the device:**
  Observe all safety instructions for any places, especially in hospital, health care facilities, service stations, schools, professional garages and on an airplane.
  Some people may experience skin irritation if they are allergic to certain substances. If you notice any signs of skin redness or swelling, please discontinue use and consult a physician.
  Persons with electronic implants (pacemakers, insulin pumps, neurostimulators, etc.) are recommended to place the device at least 15 centimeters away from the implant.
  Adhere to all safety warnings/regulations during device usage and do not use your device while driving.
  Pregnant women should keep the device away from their abdomen and teenagers should keep the device away from their lower abdomen
  Do not use the device in the event of a thunderstorm.
  Beware the allergic reaction/symptoms/transformation or dermatomyositis and remember to clean and dry the device after use.
  Failure to do so may result in damage to your device.
  Water and dust resistance are not permanent conditions and the ability will decrease as a result of normal wear.
  Do not charge your device in wet conditions.
  Do not use your device when diving over 5 meters.
  Some features such as the touchscreen may not work properly if the device is used in water.
  Do not use or store certain small parts with sharp edges that may cause an injury and may become lost and cause a choking hazard.
- Do not leave your device and its accessories within the reach of small children or allow them to play with it. They could hurt themselves or others.
- Ne laissez pas votre appareil et ses accessoires à la portée des jeunes enfants, ni ne les laissez pas jouer avec. Ils pourraient se blesser eux-mêmes ou blesser quelqu'un, ou endommager l'appareil.
- Pour éviter tout risque d'incendie, ne placez pas votre appareil ou sa batterie à proximité de sources de chaleur ou d'objets inflammables, ou sur ceux-ci (articles ayant une surface inflammable).
- Avertissement
  Ne tentez pas d'ouvrir ou de démonter l'appareil et ne tentez pas d'en utiliser pour remplacer l'opercule d'un professionnel habilité. Il n'est pas conçu ou prévu pour être utilisé dans le cadre d'une chirurgie. Il n'est pas étanche, conçu ou dans le guérison, l'stérilisation, le traitement ou la prévention d'une maladie ou d'une blessure. Il ne doit pas être utilisé en présence de la santé pourrait être affectée ou altérée à votre santé.
- Avertissement sur la batterie
  Ne fermez pas, n'écrasez pas le produit ne doit pas être démontée, trappée, entaillée ou enflammée. Placez la batterie dans un environnement à très faible pression. Ne placez pas la batterie à proximité de sources de liquide ou de gaz inflammable. Ne placez pas