

Instructions on Dismantling at end of life of Light sources and separate control gear (EU) 2019/2020

Product details

Product : Refrigerator-Freezer
Brand : SAMSUNG
Model(s) : RB3*B*****, RL3*B*****, RB3*C*****, RL3*C*****, RL39AEX

Manufacturer: : Samsung Electronics Co., Ltd
Factory
 Samsung Electronics Poland Manufacturing Sp. z o. o., ul. Mickiewicza 52,
 64-510 Wronki, Poland

- ☐ Which components are included;
 - light source(s) : Yes
 - separate control gear(s) : No

1. Tools needed

Item	How to use	Pictures
Driver	Use for assembling and disassembling of screw.	 Phillips Head Driver & Flat Head Driver

2. Dismantling LED light at end of life: Please refer to the disassembly method below.

[Precautions]

- Be sure to unplug the power cord before dismantling.
 √ Electrification
- Dismantling of Lamp(s) and Control gear(s) shall be done by Samsung Service Center or Professional repairer.

Light Source 1

1. Insert the small flat-head screwdriver at inert point's gap between liner and cover lamp.
2. Pull back the cover lamp with screwdriver.
3. Repeat twice more the #2, #3 work.
4. Separate the Cover lamp from Liner.
5. Pull up the connector area to delete the connector from led lamp.
6. Push the hook trigger and pull the connector to separate.
7. Slide out the led lamp from cover lamp.
8. Slide in the led lamp to cover lamp. (Led must located under the hook feature of cover lamp)
9. Take the same steps as mentioned earlier to assemble.

