



MiVue™ C54x / C58x



User Manual

mio™
all about you

Revision: R01
(06/2023)

Disclaimer

The screenshots in this manual may differ between different operating systems and software versions. You can download the latest User Manual of your product from Mio™ website (www.mio.com).

Specifications and documents are subject to change without notice. MiTAC does not warrant this document is error-free. MiTAC assumes no liability for damage incurred directly or indirectly from errors, omissions or discrepancies between the device and the documents.

Note

Not all models are available in all regions.

Depending on the specific model purchased, the colour and look of your device and accessories may not exactly match the graphics shown in this document.

MiTAC Europe Ltd.
The Pinnacle, Station Way, Crawley RH10 1JH, UK
MiTAC Europe Ltd. Sp. Z o. o, Oddział w Polsce
ul. Puławska 405 A, 02-801 Warszawa, Poland


Table of Contents

- Getting to know your dashcam 4
- Using a memory card 6
 - Formatting a card 6
- Using your dashcam in a vehicle 7
 - Precautions and notices 7
 - Mounting the dashcam 8
- Turning your Mio on and off 10
 - Restarting the dashcam 10
- Recording in driving mode 11
 - Continuous recording 11
 - Event recording 12
- Parking mode 13
- Camera mode 14
- Playback mode 15
- Safety camera alerts 16
 - Adding a safety camera 16
 - Updating safety camera data 17
- Customising the settings 18
 - File Playback 18
 - Sound Recording 18
 - SafetyCam 18
 - Parking Mode 19
 - Video Recording 19
 - System 20
 - Format 20

MiVue Manager	21
Installing MiVue Manager	21
Playing the recording files	21
For more information	24
Caring for your device	24
About GPS	25
Safety precautions.....	25
Regulatory information	27
WEEE.....	28

Getting to know your dashcam

 Screenshots and other presentations shown in this manual may differ from the ones generated by the actual product.



- | | |
|---------------------------|---------------------------|
| ① Mounting socket | ⑧ System indicator |
| ② Camera lens | ⑨ Microphone |
| ③ Speaker | ⑩ LCD screen |
| ④ Reset button | ⑪ Menu/Back button ** |
| ⑤ Memory card slot | ⑫ Safetycam/Up button *** |
| ⑥ Mini-USB connector | ⑬ Camera/Down Button **** |
| ⑦ Rear camera connector * | ⑭ Event/Ok Button |

* For selected models only


** Press and hold to turn the device on or off

*** Press and hold to activate Parking Mode (if enabled) monitoring

**** Press and hold to switch between dashcam and rear camera (if purchased & installed) views

MiVue rear camera

Depending on the model purchased, a rear camera may be included with the dashcam for monitoring events taking place behind the vehicle.



- ① Camera lens
- ② Mounting base
- ③ Micro-USB connector

Using a memory card

 MiTAC does not guarantee the product's compatibility with MicroSD cards from all manufacturers.

You have to insert a memory card before you can start recording. You should use separate MicroSD cards for recording and for regular data storage.

Insert the memory card before powering on your Mio. DO NOT remove the memory card during recording. Turn the device off before removing the memory card.

Hold the card (MicroSD) by the edges and gently insert it into the slot as shown in the illustration. Do not apply pressure to the centre of the memory card.

To remove a card, gently push the top edge of the card inwards to release it, and pull it out of the slot.



Formatting a card

Before you start recording, please format the MicroSD card to avoid malfunction caused by files not created by your Mio.

To format a memory card (all data will be erased):

1. Press .
2. Select **Format** and press .
3. When prompted, press  to confirm.

Using your dashcam in a vehicle


Precautions and notices

- Do not operate the device while driving. Using this product does not change the requirement for a driver to take full responsibility for his or her behaviour. This responsibility includes observing all traffic rules and regulations in order to avoid accidents, personal injuries or property damage.
- A window mount is needed when using the dashcam in a car. Make sure that you place the dashcam in an appropriate place, so as not to obstruct the driver's view or deployment of airbags.
- Make sure that no object is blocking the camera lens and no reflective material is placed near the lens. Please keep the lens clean.
- If the car's windscreen is tinted with a coating, it may impact the recording quality.
- To ensure the highest quality recordings, you are advised to place the dashcam near the rear view mirror.
- Select an appropriate location for mounting the device in a vehicle. Never place the device where the driver's field of vision is blocked.
- If the car's windscreen is tinted with a reflective coating, it may be athermic and impact the GPS reception. In this instance, please mount your device in a "clear area".
- The system will automatically calibrate the G-sensor of the device during startup. To avoid G-sensor malfunction, always turn the device on AFTER you mount it in the vehicle properly.


Mounting the dashcam

Make sure your car is parked on level ground. Follow the instructions below to mount your dashcam in a vehicle securely.


- Before attaching the device mount to the windscreen, it is recommended to clean the windscreen with rubbing alcohol and make sure that the installation area is free of dust, oil and grease.
- Attach the static cling film to the windscreen then install the mount over the static cling film.



- Route the cable through the top ceiling and the A-pillar so that it does not interfere with driving. Make sure that the cable installation does not interfere with the vehicle's airbags or other safety features.
- When adjusting the angle of mounting, make sure that the camera's view is parallel with the level ground, and the ground to sky ratio is close to a 50/50 split.
- The placement of the device and cables may vary depending on the vehicle model. If you encounter any problems during installation, contact a skilled installer (such as the service personnel of the vehicle) for assistance.



- If the model purchased includes a rear camera, follow the connection diagram below to install it.



Turning your Mio on and off

Complete the installation according to the instructions in the “Using your dashcam in a vehicle” section. Once the vehicle engine is started, the dashcam automatically turns on.

When you power on your Mio for the first time, follow the on-screen prompts to complete the following:

- Select your preferred language.
- Set up the correct date and time for your recordings.
- Set the preferred distance unit (for selected models only).

Restarting the dashcam

Occasionally, you may need to perform a hardware reset when your Mio stops responding or if it appears to be “frozen” or unresponsive. To restart your Mio, insert a pointy object (such as a straightened paperclip) into the Reset button of your Mio.

Recording in driving mode

Continuous recording

The system will automatically begin continuous recording shortly after start-up.


When recording is in progress, you can manually stop recording by pressing .

Press  to return to the recording screen; the system will start recording automatically.

The recording may be divided into several video clips; recording will not stop between video clips. When your memory card fills up with continuous recordings, it will automatically record over the oldest existing files in this category.

Continuous recordings can be found in the “Normal” category for file playback.

■ System icons



- ① Recording indicator
- ② Current time
- ③ Microphone status
- ④ GPS signal status *
- ⑤ Driving speed display *

* For selected models only

Event recording

By default, if an event happens, such as a sudden impact, high speed driving, an aggressive turn or an accidental crash during continuous recording, the G-sensor will prompt your Mio to start recording the event.

Event recording will save the duration from several seconds before until several seconds after the event. Event recording can last longer if the sensor is triggered again during recording. When your memory card fills up with event recordings, it will record over the oldest existing files in this category.

If you want to manually start an event recording while continuous recording is in progress, press the Event button (). You can manually stop recording by pressing  and the system will resume continuous recording automatically.

Event recordings can be found in the “Event” category for file playback.

Parking mode

 This feature is not available on all models.

Your dashcam supports the parking recording function. Parking mode is disabled by default. Before enabling Parking mode, please check the memory storage allocation of your device. Select  > **System** > **Storage Allocation** to set a proper allocation for parking recording. Changing the allocation will erase the memory card, so save any videos or photos to your computer first.

You can enable the function by selecting  > **Parking Mode** > **Parking Mode** > **Smart Mode** or **Passive Powered Mode**.

- **Smart Mode:** Supports recordings that are triggered by the G-sensor and motion detection. Smart parking mode is activated automatically after ignition key is in off position or when the car stops moving for about 5 minutes, depending on Auto Entry settings.

For this mode, you must use an additional power source such as Mio SmartBox uninterruptible power cable which is sold separately.

The display is turned off while operating under this mode, press any of the function buttons to activate the display.

- **Passive Powered Mode:** Supports recordings after G-sensor detections are triggered. When Passive Powered Mode is enabled, the system will enter Parking mode after the device is powered off.

While the dashcam is recording, press any of the function buttons to activate the screen. The dashcam will power off again once recording is complete.

The parking recording will save the duration from several seconds before until several seconds after an event. The parking recording can last longer if the sensor is triggered again during recording. When your memory card fills up with parking recordings, it will record over the oldest existing files in this category.

To exit Parking mode and resume continuous recording, press . If movements were detected and recorded during Parking mode monitoring, you will be asked to playback the video when you exit Parking mode.

Parking recordings can be found in the “Parking” category for file playback.

Camera mode

Press  to take a photograph with the dashcam and rear camera (if purchased and installed). Photos captured can be viewed under the “Photo” category for file playback.

Playback mode

To select a video or photo for playback:

1. Press  > **File Playback** > .
2. Select the desired type and then press .
3. Press  /  to select the desired file from the list then press .
4. Press  /  to view the previous/next file.
5. When viewing a photo, you can press  to delete the file.
6. When viewing a video, you can press  to do the following:
 - Start or pause video playback.
 - Play the corresponding rear/front video (for selected models only).
 - Delete the file.

 Deleted files cannot be recovered. Make sure to back up your files before deletion.

Safety camera alerts

 For selected models only.

 For legal reasons, the safety camera function is not available in all countries.

You can receive alerts to warn you about the locations of safety (speed) cameras which will enable you to monitor your speed through these areas.

When a safety camera appears and is positioned in the detectable direction, you will receive alerts. The screen will display a visual alert and you will also receive audio warnings.

When the alert sound setting is set to **Beep**:

- When your car approaches a safety camera, you will receive a normal beep alert.
- When your car approaches a safety camera at a speed over the set threshold, you will receive a persistent beep alert until your car speed drops lower than the appropriate speed limit.
- When your car passes through a safety camera, you will be notified by a different beep alert.

Adding a safety camera

 You can add a custom safety camera only when a GPS fix is established.

Your dashcam allows you to customise the safety camera database. You can add up to 100 custom safety cameras in your dashcam.

Follow the steps to configure a custom safety camera:

1. To add a custom safety camera in the current location, press  on the recording screen.
2. The next time you pass by the same location, you will receive alerts issued by the dashcam.

3. To view the information on the custom safety camera, select  > **SafetyCam** > **Custom SafetyCam** then select the safety camera that you want to check.
4. Press  to remove the custom safety camera from the dashcam.

Updating safety camera data

MiTAC does not warrant that all types and locations of safety camera data are available as cameras may be added, removed or relocated.

Occasionally, MiTAC may offer you updates of safety camera data. Visit the Mio website for available downloads and follow the instructions to complete update.

Customising the settings

 Not all setting items and options are available for all models.

Press  to customise system settings.

File Playback

Plays recorded videos and photos.

Sound Recording

Sets if you want to include sounds in the recordings. A system icon  is shown on the top of the recording screen if sound recording is disabled.

SafetyCam

- **Detection:** Enables or disables safety camera alerts.
- **Alert Sound:** Turns on (**Beep** or **Voice**) or off (**Mute**) the alert sound.
- **Alert Distance:** The system will alert you at a preset distance (**Short**, **Medium** or **Long**) when a safety camera is ahead.
- **Alert Method**
 - **Smart Alert:** Sets the alert distance function according to the current GPS car speed.
 - **Standard Alert:** Sets the alert distance function according to the speed limit.
- **Threshold:** Sets the speed value for the dashcam to start issuing alerts.
- **Cruise Speed Alert:** Sets the limit for the cruise speed. When you drive at a cruise speed over the set value, you will receive alerts by the dashcam.
- **Custom SafetyCam:** Lists all custom safety cameras which are sorted by the created time.

Parking Mode

- **Parking Mode:** When enabled, the dashcam will automatically start recording when it detects movements or if an event happens while the vehicle is parked.
- **Detection Method:** Sets the parking detection method to **Only G-sensor** or **Both** (motion and G-sensor).
- **Auto Entry:** Sets the mode (**Easy**, **Medium** or **Difficult**) for the system to enter Parking mode automatically.
- **G-Sensor Sensitivity:** Sets the sensitivity level of the G-sensor that allows automatic triggering of parking recording when the dashcam is in Parking Mode.
- **Motion Detection:** Sets the sensitivity level of motion detection to **Low**, **Medium** or **High**.
- **Motion Detection Area:** Sets the area of motion detection to **Whole Area** or **Main Area Only**.

Video Recording

- **Video Clip Length:** Sets the length of each video clip for a continuous recording.
- **Frequency:** Sets the frequency for the camera to avoid problems caused by artificial light sources that are not constant.
- **EV:** Sets the exposure level to adjust the brightness of the image.
- **G-Sensor Sensitivity:** Sets the sensitivity level of the G-sensor that allows automatic triggering of the event recording while continuous recording is in progress.
- **Stamps:** Sets the information (**Coordinates** or **G-Sensor**) that will be displayed on the recorded video.
- **Speed stamp:** Displays the driving speed on the recorded video.
- **Text stamp:** Displays customisable text information.

System

- **Satellites:** Displays the status of the GPS/GLONASS signal reception. You can press  and then select **GPS** or **GLONASS** for better signal reception if the need arises.
- **Date/Time:** Sets the system date and time.
 - **Use GPS time:** Select the **Time Zone** and **Daylight Saving Time** settings for your location.
 - **Manual:** Use  /  to adjust the value of the selected field; press  and repeat the step until all fields have been changed. When done, press .
- **Welcome Sound:** Enables or disables the notification sounds during start-up.
- **System Sound:** Enables or disables system notification sounds.
- **Volume:** Adjusts the volume level.
- **LCD Standby**
 - **Always On:** Keeps the LCD on.
 - **HUD:** Only displays time and speed information on the screen.
 - **10 sec / 1 min / 3 min:** Sets the timer for the LCD to turn off automatically after recording starts.
- **Language:** Sets the language.
- **Distance Unit:** Sets the preferred distance unit.
- **Storage Allocation:** The system provides 4 default memory configurations to store videos and photos. Select the proper configuration based on your usage.
- **Restore to Defaults:** Restores system settings to the factory defaults.
- **Version:** Displays software information.

Format

Formats the memory card (all data will be erased).

MiVue Manager

 Not all features are available for every model.

MiVue Manager™ is a tool for you to view videos recorded on a MiVue dashcam.

Installing MiVue Manager

Download MiVue Manager from the Support page of Mio website (www.mio.com/support) and follow the on-screen prompts to install it. Make sure to download the correct software version (Windows or Mac) according to your computer's operating system.

Playing the recording files


1. Remove the memory card from the dashcam and access the card on the computer via a card reader. You are advised to copy the recording files to your computer for backup and playback.
2. Start MiVue Manager on the computer.
 - By default, MiVue Manager shows the calendar and the file list on the right.
 - When a recording file exists, you will see the date marked with a “•”. Click that date to display the files that were recorded on that date.
 - You can select the file type to display: **Event** / **Normal** / **Parking**.
 - To display all files in the current folder, click **All**. To return to the calendar view, click **Calendar**.
3. Double-click the desired file on the file list to start playback.

4. The playback controls are described as follows:



- ❶ Skips to the previous / next file on the list.
 - ❷ Starts or pauses the playback.
 - ❸ Changes the playback speed to 1/4x, 1/2x, 1x (default), 1.5x, or 2x.
 - ❹ Mutes or unmutes the volume.
 - ❺ Adjusts the volume level.
 - ❻ Activates the Zoom Tool where a section of the image is magnified.
 - ❼ Plays the video in full screen.
 - ❽ Displays the playback progress. You can click on a point along the track bar to move directly to a different location for the playback.
5. During playback, you can view more driving information from the dashboard panel and the G-sensor chart that are displayed below the video playback screen.
- On the dashboard panel, click  to display the map screen. The map screen may not display when the computer is not connected to the Internet or when your MiVue model does not support the GPS function.
 - The G-sensor chart displays data in 3-axis waveform about the car's shift forward/backward (X), to the right/left (Y) and upward/downward (Z).

6. The tool bar allows you to do the following:



- ❶ Selects the folder that stores the recording files.
- ❷ Previews and prints the current video image.
- ❸ Saves the selected files to the specified location on your computer.
- ❹ Captures and saves the current video image to the specified location on your computer.
- ❺ Opens the Settings Menu.
 - **Change Language:** Sets the display language of MiVue Manager.
 - **Change Skin:** Sets the colour scheme of MiVue Manager.
 - **Check for Update:** Checks if there is any new version of MiVue Manager (Internet access is required for this feature).
 - **About:** Displays the version and copyright information of MiVue Manager.
- ❻ Exports the GPS information of the selected file in the KML format to the specified location on your computer.
- ❼ Opens YouTube™ on a web browser for you to upload videos (account required).
- ❽ In the playlist, the "F" and "R" marks displayed on the filename indicate that the video comes with a corresponding front video (F) or rear video (R). While playing the video, the screen displays the PIP (picture-in-picture) mode. You can switch the front and rear videos by clicking  (for selected models only).

For more information

Caring for your device

Taking good care of your device will ensure trouble-free operation and reduce the risk of damage.

- Keep your device away from excessive moisture and extreme temperatures.
- Avoid exposing your device to direct sunlight or strong ultraviolet light for extended periods of time.
- Do not place anything on top of your device or drop objects on your device.
- Do not drop your device or subject it to severe shock.
- Do not subject your device to sudden and severe temperature changes. This could cause moisture condensation inside the unit, which could damage your device. In the event of moisture condensation, allow the device to dry out completely before use.
- The screen surface can easily be scratched. Avoid touching it with sharp objects. Non-adhesive generic screen protectors designed specifically for use on portable devices with LCD panels may be used to help protect the screen from minor scratches.
- Never clean your device with it powered on. Use a soft, lint-free cloth to wipe the screen and the exterior of your device.
- Do not use paper towels to clean the screen.
- Never attempt to disassemble, repair or make any modifications to your device. Disassembling, modifying or any attempt to repair could cause damage to your device, may inflict bodily harm or damage to property and will void any warranty.
- Do not store or carry flammable liquids, gases or explosive materials in the same compartment as your device, its parts or accessories.

- To discourage theft, do not leave the device and accessories in plain view in an unattended vehicle.
- Overheating may damage the device.

About GPS

- GPS is operated by the United States government, which is solely responsible for the performance of GPS. Any change to the GPS system can affect the accuracy of all GPS equipment.
- GPS satellite signals cannot pass through solid materials (except glass). When you are inside a tunnel or building, GPS positioning is not available. Signal reception can be affected by situations such as bad weather or dense overhead obstacles (such as trees, tunnels, viaducts and tall buildings).
- GPS positioning data is for reference only.

 For selected models only.

Safety precautions

■ About charging

- Use only the charger supplied with your device. Use of another type of charger may result in malfunction and/or danger.
- This product is intended to be supplied by a LISTED Power Unit marked with “LPS”, “Limited Power Source” and output rated + 5 V dc / 2.0 A.

■ About the charger

- Do not use the charger in a high moisture environment. Never touch the charger when your hands or feet are wet.
- Allow adequate ventilation around the charger when using it to operate the device or charge the battery. Do not cover the charger with paper or other objects that will reduce cooling. Do not use the charger while it is inside a carrying case.

- Connect the charger to a proper power source. The voltage requirements are found on the product case and/or packaging.
- Do not use the charger if the cord becomes damaged.
- Do not attempt to service the unit. There are no serviceable parts inside. Replace the unit if it is damaged or exposed to excess moisture.

■ About the battery

CAUTION! This unit contains a non-replaceable internal Lithium Ion battery. The battery can burst or explode, releasing hazardous chemicals. To reduce the risk of fire or burns do not disassemble, crush, puncture or dispose of in fire or water.

- Use a specified battery in the equipment.
- Important instructions (for service personnel only)
 - Caution! Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
 - Replace only with the same or equivalent type recommended by the manufacturer.
 - The battery must be recycled or disposed of properly.
 - Use the battery only in the specified equipment.

 Applicable to models equipped with an internal battery.

Regulatory information

For regulatory identification purposes, MiVue C54x/C58x series is assigned a model number of N662.



Products with the CE marking comply with the Radio Equipment Directive (RED) (2014/53/EU) - issued by the Commission of the European Community.

Compliance with these directives implies conformity to the following European Standards:

EN 300328

EN 301489-1/-17-19+

EN 303413

EN 50498

EN 55032+24

EN 62368-1

EN 62479

IEC60950-1:2005

IEC60950-1"2005/AMD1:2009

IEC60950-1"2005/AMD2:2013

The manufacturer cannot be held responsible for modifications made by the User and the consequences thereof, which may alter the conformity of the product with the CE Marking.

Declaration of conformity

Hereby, MiTAC declares that this N662 is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

WEEE



This product must not be disposed of as normal household waste, in accordance with the EU directive for waste electrical and electronic equipment (WEEE – 2012/19/EU). Instead, it should be disposed of by returning it to the point of sale, or to a municipal recycling collection point.